

How To...

Assemble an FA Hood



1. Remove laser paper from stainless steel hood (can be gray, white, or clear in color).
2. Remove Cooking Grates, Lava Rock, Insert Pan Caps, Burner Tubes, and Insert Pans from grill.
3. Place hood on grill and secure using the self-tapping screws.
4. Screw thermometer into the mounting plate to center the logo and print prior to installing on hood.
5. Replace Insert Pans, Burner Tubes, Insert Pan Caps, Lava Rock and Cooking Grates.
6. Install hood handle brackets and hood handle.



Attach Handle Using Supplied Hardware



ALL EQUIPMENT IS FOR OUTDOOR USE ONLY.

526 EAST ROLLING RIDGE DRIVE, BELLEFONTE, PA 16823

P: 814-359-2755

F: 814-359-2621

sales@bigjohngrills.com