

How To...

Assemble a Roll-Top Hood with Brackets



1. Place hood so the vent in rear section extends over the end of the cooking grate section.
2. Slide channel with thumb screws underneath the edge on each side of the hood assembly.
3. Tighten thumb screws against the grill frame until secure.
4. Screw thermometer into the mounting plate to center the logo and print prior to installing on hood.
Please Note: Thermometer does not screw into bracket entirely. Some threads will show.
5. Attach hood handle with mounts. (See Page 2)



Close Up of How Bracket Secures Hood to Grill

How to Attach Hood Handle:



ALL EQUIPMENT IS FOR OUTDOOR USE ONLY

526 EAST ROLLING RIDGE DRIVE, BELLEFONTE, PA 16823

P: 814-359-2755

F: 814-359-2621

sales@bigjohngrills.com