

# How To Use ... Drip Tray Locks

Drip Tray Locks are recommended for grills that are highly mobile, as in catering and rental situations. They allow you to keep the drip trays in the grill and prevents them from falling out during transportation.

Pictured at left are the 3 parts that make up a **Drip Tray Lock** set. Drip Tray Lock sets fit our Country Club Grills, our Portable Grills and our Trail Boss Towable Grills. A set consists of:

- The Drip Tray Locks
- The Attachment Rods
- Cotter Pins



Model	fits these Models	# of Locks	# of Rods	# of Pins	Price
<b>DTL4</b>	A4CC, A4P, TB I & II	4	2	4	<b>\$15.00</b>
<b>DTL3</b>	A3CC & A3P	3	2	4	<b>\$13.00</b>
<b>DTL2</b>	A2CC & A2P	2	1	2	<b>\$10.00</b>

- 1 Locate bottom hole in between grill bay sections on your A-Series Grill. Use this hole for mounting your drip tray locks.
- 2 Insert attachment rod in bottom hole of grill frame.
- 3 Slide Drip Tray Lock on each side of Attachment Rod, as pictured. Insert 1 Cotter Pin through the hole on each side of the Attachment Rod. Slide Drip Tray back until Lock engages.

