

THIS INSTRUCTION MANUAL CONTAINS IMPORTANT INFORMATION NECESSARY FOR THE PROPER ASSEMBLY AND SAFE USE OF THIS PRODUCT.
CETTE NOTICE CONTIENT DES RESEIGNEMENTS IMPORTANTS PERMETTANT UN ASSEMBLAGE ADÉQUAT ET À UNE UTILISATION SÉCURITAIRE DE L'APPAREIL.



SL30L

Read and follow all warnings and instructions in included instruction manual before assembly and use of appliance.
Lisez et suivez attentivement toutes les instructions dans le manuel d'instructions fourni avant le montage et l'utilisation de l'appareil.

Model: SL30L

- 30,000 BTU Cast Aluminum Burner
- Appliance Style Temperature Controls
- Large Cooking Surface
- Convenient Cooking Height



SL30L INSTRUCTIONS AND TROUBLE SHOOTING

1. Remove handle bolt from bottom of stove. Reverse legs and install as shown. Make sure the legs are centered in the grooves of the drum and tighten handle bolt. (Fig 1)
2. Screw out thumb screws until flush with inside of cooker leg. Apply extension to each leg. Hand tighten thumb screws. (Fig 2)
3. Stand cooker upright on solid level ground. To level: loosen thumb screw on leg extension and adjust leg height. Hand tighten thumb screw. (Fig 3)

BURNERS WILL NOT IGNITE

1. Make sure there is propane in the tank and turn propane tank is turned on.
2. Follow all instructions in instruction manual for lighting the burner

YELLOW FLAME

1. Adjust Air Shutter until burner has blue flame. Some yellow tipping of the flame is normal.
2. See Instruction Manual for Cleaning the burner

FLAME IS VERY SMALL AND WON'T INCREASE.

1. Make sure there is propane in the tank and turn propane tank is turned on a minimum of 3 full turns
2. Follow all instructions in manual for leak testing the stove.
3. Turn all valves on the stove to the off position. Turn the Propane Tank off. Disconnect regulator from the tank. Reconnect regulator to the tank. Slowly turn tank on. Follow all instructions in the manual for leak testing the stove. If no leaks are found follow all instructions in the manual for lighting the appliance.

MAX POT DIAMETER 10"
254MM DIAMÉTRE MAXIMUM DU POT

FOR OUTDOOR USE ONLY
UNIQUEMENT POUR L'EXTÉRIEUR


KEEP FOR FUTURE REFERENCE
GARDEZ POUR RÉFÉRENCE ULTÉRIEURE

Regulator Model
150/451, R329, RA329, RJ-A
JY70-003, JY95A7A (JY95-007)
RYQ Series (RYQF01)

3985 N 75 W, Hyde Park, UT 84318 • 800.650.2433 • www.CampChef.com

WARNING: Chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm are created by the combustion of propane.
Sport Utility, Big gASS Grill, Keg Roaster, Ultimate Roaster Are From the Makers of Camp Chef and Covered Under One or More of the Following Patents: 356714, 378646, 417120, 328547, 358057, 364772

SL30L PARTS LIST



0313SL30parts

