How To...

Attach a 5" Caster Wheel Brake Kit



TOOLS:

- Caster Brake Kit (1 Kit Per Wheel)
 (includes brake, foot pedal, longer bolt, nylon lock nut)
- (1) 9/16" wrench
- (1) ½" wrench



STEP 1:

Disassemble current casters by taking nut off bolt and pulling old bolt out. *Discard old bolt*.



STEP 3:

Put wheel between forks of yoke and run new longer bolt with tabs facing outward, away from wheel and the "on/ off" symbols facing upward



STEP 2:

Put new caster brake on yoke by inserting tab on brake into the slot on the side fork of the yoke while also lining up the slotted hole with the bolt hole on yoke. The shoe of the brake will be on the inside of the yoke, near the top.



STEP 4:

Attach nylon lock nut to bolt and tighten. Do not over tighten or wheel will not spin.



ALL EQUIPMENT IS FOR OUTDOOR USE ONLY

526 EAST ROLLING RIDGE DRIVE, BELLEFONTE, PA 16823